



## AUDIO, CONT.

PHILIPS	0755	0814				
0823	0824	0825				
PIIONEER	0837	0866				
0867	0878	0893				
RADIO SHACK	0706	0754	0793			
0806	0865	0866	0867			
0868	0875	0878	0879			
RCA	0827	0845	0866	0867	0870	0871
0872	0875	0878	0879	0449	0895	
REALISTIC	0822					
RIO	0405					
SABA	0894					
SAMSUNG	0454					
SONY	0705					
SCOTT	0768					
SHARP	0671	0684	0809			
SHERWOOD	0706	0806	0858	0859		
SKYTT	0725					
0785	0797	0798	0799	0833		
0834	0835	0836	0843	0909		
TAO	0725					
TEAC	0710	0807	0855	0856	0857	
TECHNICS	0791	0810	0815			
0823	0863	0864				
TEVION	0448					
VENTURER	0448					
XM RADIO	0708	0725				
YAMAHA	0801	0802	0838	0840		
0841	0846	0847	0848	0849		
ZENITH	0676	0730	0749			
0759	0765	0766	0784			
0814	0787	0850	0405			

## CABLE

ABC	0461	0463	0464	0465	0466
ADELPHIA	0512	0511			
ALLLEGRO	0524	0525			
AMERICAST	0527				
ANTROXIX	0468	0469			
ARCHER	0468	0469	0470	0471	
AT&T	0511				
BELL SOUTH	0527				
CABLETENNA	0468				
CABLEVISION	0468				
0506					
CENTURY	0471				
CITIZEN	0471				
COGECO	0511				
COLOR VOICE	0472	0473			
COMCAST	0511				
COMTRONICS	0474	0475			
CONTEC	0476				
DIGITAL MUSIC EXPRESS	0514				
EASTERN	0477				
EVERQUEST	0474				
GARRARD	0471				
GC ELECTRONICS	0469				
GEMINI	0536	0479			
GE	0549				

GENERAL INSTRUMENT (GI)	0509				
0461	0465	0511	0513	0518	
0530	0531	0514	0464	0463	
HAMLIN	0461	0480	0481	0482	
HITACHI	0463				
ILLICO	0506				
JASCO	0471				
JERROLD	0509	0461	0465	0518	
BELL EXPRESSVU	0463	0464	0520	0526	
MAGNAVOX	0485				
MEMOREX	0486				
MOTOROLA	0509	0465	0513	0518	
0530	0531	0464	0511	0526	0463
MOVIE TIME	0487				
CHEYENNE	0561				
NSC	0487				
OAK	0476	0489			
PACE	0532				
PANASONIC	0460	0508			
PARAGON	0486	0488			
PHILIPS	0471	0479	0485		
PHILIPS-MAGNAVOX	0490	0491	0492		
PHILIPS-MAGNAVOX	0505	0534			
PIONEER	0478	0506	0493	0494	
PULSAR	0486				
RADIO SHACK	0505	0524	0525		
RCA	0460	0471	0507		
REALISTIC	0469				
REGAL	0482				
REGENCY	0477				
REMBRANDT	0463				
ROGERS	0506				
RUNCO	0486				
SAMSUNG	0474	0494			
SCIENTIFIC ATLANTA	0498	0497			
0506	0535	0512	0466	0496	
SHAW	0511				
SIGNAL	0474				
SIGNATURE	0463				
SL-MARX	0474				
SPRUCER	0460				
STANDARD	0499				
STARCOM	0461	0518			
STARGATE	0474				
STAR SIGHT	0507				
STAR TRAK	0516				
TANDY	0500				
TELEVIEW	0474				
TEXSCAN	0499				
TIME WARNER	0506				
TOCOM	0464	0501	0513	0520	
TOSHIBA	0486				
MITSUBISHI	0641	0632	0638		
TV86	0629	0630	0607		
MOTOROLA	0648	0618			
NORSTAT	0601				
UNIVERSAL	0468	0469	0470		
VIDEOWAY	0504				
VIEWSTAR	0475	0485	0487	0500	
VIDEO TECH	0550				
VIDEOTRON	0506				
ZENITH	0503	0525	0471		
0486	0521	0522	0523		
ZENITH NETWORK	0527				

## SAT/DTV/WebTV

Where codes are shown like this [###] each one can be used if you have 2 or more of the SAME device.

AMPICA	0575					
BELL EXPRESSVU	0654	0477				
0655	0628					
CHANNEL MASTER	0577					
0578	0579					
CHAPARRAL	0560	0561				
CHEYENNE	0561					
DRAKE	0562	0574	0587			
DREAMBOX	0620					
DIRECTV	0622	0632	0629	0621		
0630	0634	0636	0638	0641	0652	
0653	0657	0659	0607	0619	0641	
DISH NETWORK	[0653] [0647]					
DISHPRO	0628	0612	0654	0588	0589	0590
DX ANTENNA	0588	0589	0590	0654		
ECHOSPHERE	0568	0582				
ECHOSTAR	[0653] [0647]					
0628	0612	0654	0588	0589	0590	
EXPRESSVU	0654	0647	0655	0628		
FORTEC STAR	0569	0555	0556			
AIWA	0557	0558	0559			
AMES	0591	0592				
AMW	0917	0918				
ANABA	0961					
APEX	0386	0390	0391	0392		
0424	0430	0436	0439	0445		
0457	0459	0938	0913	0401	0949	
ASPIRE	0933					
A-TREND	0393					
AUDIOVOX	0921					
AXION	0921					
B & K	0978					
BLAUPUNKT	0430					
BODYSONIC	0417					
BOSE	0672					
BOSS	0911					
BROKSONIC	0932	0967	0394			
CENTRIOS	0951	1067	1068	0921		
0105	1054	1055	1059	1060		
01061	1064	1065	1062	0449		
CHANGHONG	0401					
CINEVISION	0405					
CITECH	1073					
CITIZEN	1073					
CLASSIC	0431	1051	0401			
COBY	0926	0946	0947			
0916	0445	0928	0894			
CONCEPT	0430					
CRITERION	0448					
CURTIS INTERNATIONAL	0929					
0903	0896	0959				
0928						
MEMOREX	0446	1050				
CYBERHOME	0393	0985	0939			
CYTRON	0446	0388				
DAEWOO	0440	0441				
0444	0971	0665				
DENON	0400	0421				
DENZEL	0428					
DESAY	0958					
0636	0649	0637	0622	0658		
0653	0650	0651	0652	0998		

REALISTIC	0567	0603			
SAMSUNG	0594	0583			
0613	0616	0619			
SHARP	0604				
SKY NETWORK	0614	0615	0646		
SIERRA 11111	0561				
SONY	0623	0657	0659	0585	0602
DURABRAND	0449	0405	0446		
DVD 2000	0402				
STAR SIGHT	0434	0435			
STAR TRAK	0405	0400			
EMERSON	0396	0400	0974		
0899	0456	0458			
ESA	0956				
SYLVANIA	0581				
FARENHEIT	0960				
FISHER	0916				
FUNAI	0456	0458			
GE	0409	0430			
GOLDSTAR	0405				
GO-VIDEO	0431	0937	0971		
0454	0902	0901	0407	0426	0455
GPX	0936	0944			
GRADIENTE	0415				
GREENHILL	0430				
HAAZ	0451	0452			
HAIER	0935				
HARMAN KARDON	0427				
HITACHI	0404	0407	0428	0410	
HITEK	0445				
HUMAX	0912				
ILO	0959	1070			
INFINITY	0417				
INSIGNIA	0405	0456			
0921	0430	1070			
INITIAL	0451				
INTEGRA	0422				
JBL	0427				
JVC	0406	0964	0900		
1072	0418	0923			
JWIN	0919				
KAWASAKI	0945	0449			
KENWOOD	0400	0429			
KISS	0428				
KLH	0430	0906	0386		
KONKA	0410	0411			
0412	0413	0905			
0415	0388				
0894					
LASONIC	0451	0948			
LENNOX	0931	0435			
0405	0972	0907			
LINN	0443				
LITEON	0982	0902	0898	0959	1069
LIQUIDVIDEO	0921				
LIQUIDVIDEO	0921				
MAGNAVOX	0398	0408	0979	0981	
0980	0456	0915	0914	0969	
0398	0405				
0408	0423	0981			
MAXENT	0923				
MEDION	0911	0446			
0903	0896	0959			
0928					
MEMOREX	0446	1050			
MERIDIAN	0398				
MICROSOFT	0409				
MINTEC	0430				
MITSUBISHI	0402				
MUSTEK	0431				
MYRON & DAVIS	0962				
NAD	0405	0433			
NAKAMICHI	0432				

DIAMOND VISION	0948				
NEXXTECH	0952	0954	0955		
0956	0934	1052	1054	1055	
1056	1057	1063	1064	0409	0949
DISNEY	0458				
NORCENT	0926	0982			
0927	0925	0928			
DURABRAND	0449				
ONKYO	0422	0975			
ORITRON	0404				
OPTIMUS	0394				
ELTA	0415	1060			
ORITRON	0415	1060			
PANASONIC	0396	0400	0974		
0396	0400	0974			
PACIFIC	0970	0437	0950	0387	
0446					
PHILIPS	0398	0408	0423	0755	
0979	0981	0980	0456	0458	0969
PHILIPS-MAGNAVOX	0398	0408			
0423	0979	0980			
PIONEER	0403	0404	0976		
0977	0968	0909	1084		
PIVA	1075				
POLAROID	0385	0957	0949		
POLAROID	0398	0408	0981		
PORTLAND	0435				
PROLINE	0415				
HARMAN KARDON	0409	0890			
PROSCAN	0431				
PROSONIC	0926				
PYLE	0910				
RADIO SHACK	0449	0453			
RCA	0409	0430	0449		
0919	0920				
0453	0920	0890			
REGENT	0931				
REOC	0385				
RIO	0405				
RJ TECHNOLOGY	0373				
ROSEN	0930				
ROTEL	0406				
SABA	0390	0893	0895		
SAMSUNG	0407	0454	0942		
0963	0891	0455			
SAMPO	0417				
SANSUI	0394	0967			
SANSUI	0904	0416			
SEARS	0394	0456			
SEG	0428				
SELECTRON	1077	1078	1079		
1080	1081	1082	1083		
SHARP	0397	0897	0908		
SHERWOOD	0425				
SHINCO	0430				
SHINSONIC	0430				
SONIC BLUE	0937				
SONY	0987	0988	0989		
0399	0986	0389			
0910	0913				
0408	0423	0981			
SUPERSCAN	0456				
SUPERSONIC	0944				
SV2000	0456				
SYLVANIA	0456	0458			
SYMPHONIC	0456	0458	0899		
TEAC	0404	0449			
TECHNICS	0400				
TECHWOOD	0433	1071			
TERAPIN	0943				
0388	0446	0447			
0448	0450	0451	0452		
0404					

NESA	0430	0962			
0952	0954	0955			
0956	0934	1052	1054	1055	
1056	1057	1063	1064	0409	0949
DISNEY	0458				
NORCENT	0926	0982			
0927	0925	0928			
DURABRAND	0449				
ONKYO	0422	0975			
ORITRON	0404				
OPTIMUS	0394				
ELTA	0415	1060			
ORITRON	0415	1060			
PANASONIC	0396	0400	0974		
0396	0400	0974			
PACIFIC	0970	0437	0950	0387	
0446					
PHILIPS	0398	0408	0423	0755	
0979	0981	0980	0456	0458	0969
PHILIPS-MAGNAVOX	0398	0408			
0423	0979	0980			
PIONEER	0403	0404	0976		
0977	0968	0909	1084		
PIVA	1075				
POLAROID	0385	0957	0949		
POLAROID	0398	0408	0981		
PORTLAND	0435				
PROLINE	0415				
HARMAN KARDON	0409	0890			
PROSCAN	0431				
PROSONIC	0926				
PYLE	0910				
RADIO SHACK	0449	0453			
RCA	0409	0430	0449		
0919	0920				
0453	0920	0890			
REGENT	0931				
REOC	0385				
RIO	0405				
RJ TECHNOLOGY	0373				
ROSEN	0930				
ROTEL	0406				
SABA	0390	0893	0895		
SAMSUNG	0407	0454	0942		
0963	0891	0455			
SAMPO	0417				
SANSUI	0394	0967			
SANSUI	0904	0416			
SEARS	0394	0456			
SEG	0428				